











RSLogix 5000 - Controller in ENB301MI_Test.ACD [1756-L55]* - [Controller Tags - Controller(controller)]

File Edit View Search Logic Communications Tools Window Help

Rem Run Run Mode Controller OK Battery Fault I/O Not Responding

Path: AB_ETHIP-1\192.168.0.147\Backplane\0*

Name	Value	Force Mask	Style	Data Type	Description
+ Gateway.0	(...)	(...)		AB:ETHERN...	
- Local:1:	(...)	(...)		AB:1756_DN...	
+ Local:1: StatusRegister	(...)	(...)		AB:1756_DN...	
Local:1: Data					
+ Local:1: Data[0]	16#0000_0000	Hex		DINT	
+ Local:1: Data[1]	16#1200_0100	Hex		DINT	
+ Local:1: Data[2]	16#0000_0300	Hex		DINT	
+ Local:1: Data[3]	16#0000_0000	Hex		DINT	
+ Local:1: Data[4]	16#0000_0000	Hex		DINT	
+ Local:1: Data[5]	16#0000_0000	Hex		DINT	
+ Local:1: Data[10]	16#0000_0000	Hex		DINT	
+ Local:1: Data[11]	16#0000_0000	Hex		DINT	
+ Local:1: Data[12]	16#0000_0000	Hex		DINT	
+ Local:1: Data[13]	16#0000_0000	Hex		DINT	
+ Local:1: Data[14]	16#0000_0000	Hex		DINT	

Configuration

- 1756 Backplane, 1756-A7
- [0] 1756-L55 Controller
- [1] 1756-DNB DeviceNet_master
- [2] 1756-ENBT/A Bridge
- Ethernet
 - ETHERNET-MODULE Gateway
 - 1756-ENBT/A Bridge